

WEEK 45 EARLY NOVEMBER • ~5 MIN READ • ONTARIO CONSTRUCTION

Cold Weather Preparedness

The first hard freeze comes fast in Ontario. It catches crews before anyone's back in the habit of watching their footing — and it catches the site too: a cracked water line, a hose frozen solid, a machine that ran fine yesterday. An hour of prep now keeps people on their feet; the saved machines are the bonus.

The hazard

Frozen ground and overnight ice hide slip and trip hazards — pooled water, wet plywood, churned mud all turn slick by morning, and the slips start before the first real snow. The cold is hard on the site itself too: water expands when it freezes and splits pipes, pumps and fittings, fuel can gel, and batteries lose capacity. A site that isn't ready loses mornings to burst lines and machines that won't start.

What to do — people first

- ▶ **Give the surfaces an owner, all shift.** Work areas, the routes to and from them, and scaffold platforms in use have to be kept clear of snow and ice and sanded when footing needs it — **at all times, not once in the morning.** Assign who inspects, clears, and re-treats as conditions change, and close a route that can't yet be made safe.
- ▶ **Stockpile sand, salt, or grit now,** at the entrances, stairs, and walkways where it'll be needed, and keep it topped up.
- ▶ **Get the shovels, scrapers, and a working snow blower on site** before the first storm, not during it.
- ▶ **Check the warm-up arrangements** — somewhere genuinely warm, and a break schedule that will flex with wind chill once it drops.

Then the site and the gear

- ▶ **Drain water lines, pumps, hoses, and pressure washers at the end of the day.** If you blow lines out with compressed air, do it the way the equipment's instructions say — regulated pressure, eye protection, nobody in the discharge path. Improvised air is its own injury.
- ▶ **Fuel, coolant, and batteries follow the manufacturer's specification for that machine,** not a rule of thumb. Winter fuel and conditioner ahead of the cold, coolant checked against its rated protection, block heaters used as the maker intends — and inspect the cords and connections before you plug anything in outside.
- ▶ **Store small tools, batteries, and adhesives per their instructions.** Cold flattens battery charge and ruins some glues and sealants; heated storage helps, but check what the product actually calls for.

Watch out for

- ▶ Pooled water that becomes a hidden sheet of ice by morning.
- ▶ A machine that cranks slow or won't start — that's a warning, not just a delay. Don't force it.
- ▶ Hoses or lines left full "just for tonight." That's how they split.
- ▶ Damaged extension cords and block-heater leads under snow — a wet, damaged cord outdoors is an electrical hazard, not an inconvenience.

Talk it over

- ▶ Where will ice show up first here — shaded walkways, ramps, plywood, stairs — and who's checking and re-treating them tomorrow morning?
- ▶ What on this site still has water in it right now?
- ▶ Is the warm-up area actually warm, and does everyone know where it is?



A SIGNATURE PROVES ATTENDANCE. DASHPOT
PROVES UNDERSTANDING.

Get a new toolbox talk every week — free.

Dashpot Safety turns the morning talk into a per-worker
record of what each crew member actually understood, by
SMS in about five minutes.

SCAN FOR THE FULL LIBRARY →
[DASHPOT.CA/TOOLBOX-TALKS](https://dashpot.ca/toolbox-talks)

This toolbox talk is general safety information for Ontario construction — not legal advice, and not a substitute for your own site-specific hazard assessment, worker training, and health-and-safety program. Follow the current Occupational Health and Safety Act and its regulations, manufacturer instructions, and your employer's procedures. Provided as-is, without warranty — you use it at your own risk.